

Instructions on how to use 3D ChocoPrinter

Università della Svizzera Italiana

Version August 18, 2020

Contents

1	Setup	2
1.1	Download	2
1.2	Configuration	2
2	Steps involved in 3D Printing	2
3	Firmware update	3

1 Setup

1.1 Download

The following software is needed:

- Repetier-Host, <https://www.repetier.com/download-now>
- Slicer configurations, https://3dprint.elettronica.in.it/wp-content/uploads/2015/10/Configurazione-3DRAG-Choco/Config_Slic3r_CHOCO.zip

To update the printer firmware (optional):

- Arduino IDE 1.0.6, <https://www.arduino.cc/en/Main/OldSoftwareReleases>
- Printer firmware, TODO

1.2 Configuration

Install the Repetier-Host software on your machine and start it. Click on the tab **Slicer** and then on the button **Configure**. Click on **Cancel** to close the wizard and the menu **File** to choose **Load Config**. Choose the file `Slic3r_config_bundle.ini` under **Configurazione-Repetier/3DRAG Choco/Config Slic3r_CHOCO** from the downloaded configuration package.

Click on the gear next to the field **Print settings**, then on the save icon next to the profile name, save it with a suitable name (eg "ChocoPrinter") and confirm with **Ok**. Close the tab and repeat the operation with the fields **Filament** is **Printer**.

When finished, close the window **Slicer** and choose the new profiles just created from the panel **Slic3r** by Repetier-Host.

//TODO config stampante?

2 Steps involved in 3D Printing

- 1) Start the SW Repetier-Host
- 2) Turn on the printer
- 3) Connect to the printer (configure it if not already done)
- 4) Insert the chocolate into the syringe
- 5) Insert the needle into the syringe and then insert the syringe into the aluminum rod
- 6) Insert the syringe with the needle into the aluminum rod and place the syringe with the rod in

the cylinder of the printer

- 7) If necessary, lift the holder, by clicking on Retract, to correctly insert the syringe
- 8) Heat the chocolate to 30 ° C. At first, if the temperature exceeds 33 ° C, turn off the heating. Keep the temperature between 30 and 33 degrees
- 9) Wait for the chocolate to come out of the syringe
- 10) Click on Print Panel and place the printer in "Home All"
- 11) Click on Object Placement and choose the object (* .stl file) to print
- 12) Change the size of the object if necessary, changing the number of the "Scale" field
- 13) Click on Slicer and select "Slice with Slic3r"
- 14) To print click on Run

3 Firmware update

Note: this procedure requires a version 1.0.x of Arduino IDE, which is not compatible with MacOS from High Sierra 10.13.4 onwards.

Download the appropriate firmware (3Drag Choco - LCD xxx version, green or black controller) from the website indicated in the section 1.1.

IMPORTANT: choose the correct version! Loading the wrong firmware may make the printer unusable!

Extract the firmware package and open the file `Marlin.ino` in the folder `Marlin`. From menu `Sketch > Import Library...` choose `Add Library...` and select the folder `libraries/U8glib` in the previously downloaded folder. from menu `Tools > Board` to select `Arduino Mega 2560 or Mega ADK` and from menu `Tools > Serial Port` select the COM port associated with the printer. Check on the printer board that the JPROG jumper is inserted. Click on the second button from the left (**Upload**) and wait for the procedure to complete. At the end of the procedure, disconnect the printer power supply or press the reset button on the card itself.